

# QGNSS User Guide

## GNSS Module Series

Version: 2.2

Date: 2024-01-09

Status: Released



At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

**Quectel Wireless Solutions Co., Ltd.**

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: [info@quectel.com](mailto:info@quectel.com)

**Or our local offices. For more information, please visit:**

<http://www.quectel.com/support/sales.htm>.

**For technical support, or to report documentation errors, please visit:**

<http://www.quectel.com/support/technical.htm>.

Or email us at: [support@quectel.com](mailto:support@quectel.com).

## Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an “as available” basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

## Use and Disclosure Restrictions

### License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

### Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

## Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by Quectel or any third party in advertising, publicity, or other aspects.

## Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties ("third-party materials"). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

## Privacy Policy

To implement module functionality, certain device data are uploaded to Quectel's or third-party's servers, including carriers, chipset suppliers or customer-designated servers. Quectel, strictly abiding by the relevant laws and regulations, shall retain, use, disclose or otherwise process relevant data for the purpose of performing the service only or as permitted by applicable laws. Before data interaction with third parties, please be informed of their privacy and data security policy.

## Disclaimer

- a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
- b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
- c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
- d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

**Copyright © Quectel Wireless Solutions Co., Ltd. 2024. All rights reserved.**

# About the Document

Document Information	
Title	QGNSS User Guide
Subtitle	GNSS Module Series
Document Type	User Guide
Document Status	Released

## Revision History

Version	Date	Description
1.0	2020-01-03	Initial
2.0	2023-05-23	<ol style="list-style-type: none"> <li>Updated the tool version to V1.8.</li> <li>Numerous changes were made to this document. It should be read in its entirety.</li> <li>Adjusted the scope of application from LC79D to all GNSS modules.</li> </ol>
2.1	2023-10-16	<ol style="list-style-type: none"> <li>Updated the tool version to V1.9.</li> <li>Added QuecRTK function (<a href="#">Chapter 1</a>).</li> <li>Updated Deviation Map and related icons to show more detailed positioning information (<a href="#">Chapter 2.2.3.5</a>).</li> <li>Added the “Calculation Distance” tool in the coordinate converter window (<a href="#">Chapter 2.2.5.3</a>).</li> <li>Added QuecRTK Client and Data Monitor pages (<a href="#">Chapters 3.8.2</a> and <a href="#">3.8.3</a>).</li> <li>Added the figure of firmware download process (<a href="#">Figure 50</a>).</li> </ol>
2.2	2024-01-09	Updated the tool version to V1.10.

## Contents

About the Document .....	3
Contents .....	4
Table Index .....	6
Figure Index .....	7
<b>1 Introduction .....</b>	<b>9</b>
<b>2 User Interface Description .....</b>	<b>10</b>
2.1. Main Window .....	10
2.2. Menu Bar .....	11
2.2.1. File Tab .....	11
2.2.2. Device Tab .....	11
2.2.3. View Tab .....	12
2.2.3.1. Data Dock Sub-Window .....	13
2.2.3.2. Unparsed Data Sub-Window .....	14
2.2.3.3. Text Data Sub-Window .....	15
2.2.3.4. Binary Data Sub-Window .....	16
2.2.3.5. Deviation Map Sub-Window .....	17
2.2.3.6. GNSS Signal View (Signal Level) Sub-Window .....	19
2.2.3.7. Sky View Sub-Window .....	20
2.2.3.8. Messages View Sub-Window .....	21
2.2.3.9. Configuration View Sub-window .....	22
2.2.4. Setting Tab .....	23
2.2.5. Tools Tab .....	24
2.2.5.1. Command Console .....	25
2.2.5.2. NMEA Convert KML .....	26
2.2.5.3. Coordinate Converter .....	27
2.2.6. DR Tab .....	30
2.2.7. AGNSS Tab .....	30
2.2.8. Windows Tab .....	31
2.2.9. Help Tab .....	32
2.3. Tool Bar .....	33
<b>3 Common Operations .....</b>	<b>35</b>
3.1. Connect to Receiver .....	35
3.2. Log Play .....	36
3.3. Restart Receiver .....	37
3.4. TTFF .....	38
3.5. Configure Receiver .....	39
3.6. Send Command .....	41
3.7. Send AGNSS Data .....	42
3.8. NTRIP .....	44
3.8.1. NTRIP Client .....	44

3.8.2.	QuecRTK Client .....	46
3.8.3.	Data Monitor .....	47
3.9.	Firmware Download .....	48
<b>4</b>	<b>Appendix References .....</b>	<b>50</b>

## Table Index

Table 1: Deviation Map Function Description .....	18
Table 2: Signal View Function Description.....	19
Table 3: Command Console Function Description.....	25
Table 4: Description of Tool Bar Functions.....	33
Table 5: Controller Function Description .....	37
Table 6: Terms and Abbreviations .....	50

## Figure Index

Figure 1: Main Window .....	10
Figure 2: File Tab.....	11
Figure 3: Device Tab .....	11
Figure 4: View Tab.....	12
Figure 5: Data Dock Sub-Window.....	13
Figure 6: Unparsed Data Sub-Window .....	14
Figure 7: Text Data Sub-Window .....	15
Figure 8: Binary Data Sub-Window.....	16
Figure 9: Deviation Map Sub-Window .....	17
Figure 10: Signal View (Signal Level) Sub-Window .....	19
Figure 11: Sky View Sub-Window .....	20
Figure 12: Messages View Sub-Window .....	21
Figure 13: Configuration View Sub-Window .....	22
Figure 14: Setting Tab Menu .....	23
Figure 15: Settings Dialog.....	23
Figure 16: Tools Tab Menu .....	24
Figure 17: Command Console Tool .....	25
Figure 18: NMEA Convert KML Tool .....	26
Figure 19: Coordinate Converter Tool – Enter Values .....	27
Figure 20: Coordinate Converter Tool – Convert Values .....	28
Figure 21: Calculate Distance Tool .....	29
Figure 22: DR Status Window .....	30
Figure 23: AGNSS Window.....	30
Figure 24: Window Tab Menu .....	31
Figure 25: Tile Pattern Window .....	31
Figure 26: Cascade Window .....	32
Figure 27: Help Tab Menu.....	32
Figure 28: Tool Bar .....	33
Figure 29: Open Serial Port Configuration.....	35
Figure 30: Serial Port Configuration Dialog .....	35
Figure 31: Log Play .....	36
Figure 32: Select the File .....	36
Figure 33: Play Controller .....	37
Figure 34: Restart Receiver .....	37
Figure 35: Open TTFF Window.....	38
Figure 36: TTFF View.....	38
Figure 37: Open Configuration View .....	39
Figure 38: Configuration View.....	40
Figure 39: Open Command Console .....	41
Figure 40: Open AGNSS Window .....	42
Figure 41: Connect to FTP Server .....	42



Figure 42: Download AGNSS File.....	43
Figure 43: Send AGNSS Data.....	43
Figure 44: Open NTRIP Client .....	44
Figure 45: NTRIP Client .....	45
Figure 46: Set Manual Position .....	45
Figure 47: QuecRTK Client .....	46
Figure 48: RTK Data Monitor .....	47
Figure 49: Open Firmware Download .....	48
Figure 50: Firmware Download Process.....	49

# 1 Introduction

QGNSS is a tool that allows you to interact with Quectel GNSS modules quickly and easily. It enables evaluation, performance testing, development and debugging of Quectel GNSS modules. Tool features are listed below:

- Supports receivers utilizing standard NMEA strings in compliance with NMEA 0183 V4.11 and previous versions.
- Supports the parsing of RTCM3.x protocol messages.
- Supports log replay.
- Presents all the information collected by the GNSS device. All aspects of GNSS data (positioning, velocity, time, satellite tracking, etc.) can be monitored and logged under various test scenarios for receiver evaluation.
- Supports the downloading of AGNSS data.
- Supports NTRIP client.
- Supports the downloading of firmware update packet to GNSS positioning modules.
- Supports QuecRTK.

# 2 User Interface Description

## 2.1. Main Window

The window illustrated below is the main display window of QGNSS. It shows the menu bar, tool bar and positioning information. You can open the sub-window in the central area.




Figure 1: Main Window

## 2.2. Menu Bar

### 2.2.1. File Tab

In the “**File**” tab menu:

- Click “**Open**” to open the play dialog box. See [Chapter 3.2 Log Play](#) for details.
- Click “**Show Logfile in Explorer**” to open the folder of the saved log file.
- Click “**Quit**” to close QGNSS.




Figure 2: File Tab

### 2.2.2. Device Tab

In the “**Device**” tab menu:

- Click “**Connect**” to connect to the receiver.
- Click “**Set Device Information**” to configure serial port information. See [Chapter 3.1 Connect to Receiver](#) for details.




Figure 3: Device Tab

#### NOTE


Make sure to configure the serial port information before connecting to the receiver.

### 2.2.3. View Tab

In the “**View**” tab menu:

- Click “**Clear**” to clear the data displayed in the Unparsed Data, Text Data and Binary Data.
- Click “**Online Map**” to view the real time location reported by the module on a map.


See the following sections for more details about other tabs.



**Figure 4: View Tab**

### 2.2.3.1. Data Dock Sub-Window

The “**Data Dock**” sub-window displays detailed information such as longitude and latitude, altitude, and fix mode.



The screenshot shows a window titled "Data Dock" with a close button (X) in the top right corner. The window contains a list of 20 data fields, each with a corresponding text input box to its right. The fields are: Longitude, Latitude, Altitude(MSL), Altitude(EPH), Speed(km/h), HDOP, PDOP, Fix Mode, Quality Indicator, Date(UTC), Time(UTC), Total Epochs, Fixed Epochs, RTK Fixed, RTK Float, Age Of Diff, TTFF(s), 2D Acc(m), and 3D Acc(m).

Longitude	
Latitude	
Altitude(MSL)	
Altitude(EPH)	
Speed(km/h)	
HDOP	
PDOP	
Fix Mode	
Quality Indicator	
Date(UTC)	
Time(UTC)	
Total Epochs	
Fixed Epochs	
RTK Fixed	
RTK Float	
Age Of Diff	
TTFF(s)	
2D Acc(m)	
3D Acc(m)	

Figure 5: Data Dock Sub-Window

### 2.2.3.2. Unparsed Data Sub-Window

The “**Unparsed Data**” sub-window displays data sent by the receiver, and offers control options at the bottom such as “**Clear**”, “**Timestamp**”, and “**Pause**” buttons, along with and “**Filter**” feature.




Figure 6: Unparsed Data Sub-Window

### 2.2.3.3. Text Data Sub-Window

The “Text Data” sub-window displays the NMEA messages, and offers control options at the bottom such as “Clear”, “Timestamp”, and “Pause” buttons, and with a “Filter” feature.




Figure 7: Text Data Sub-Window



#### 2.2.3.4. Binary Data Sub-Window

The “**Binary Data**” sub-window displays the message of the binary protocol, and offers control options at the bottom such as “**Clear**”, “**Timestamp**”, and “**Pause**” buttons, and a “**Filter**” feature.





Figure 8: Binary Data Sub-Window

### 2.2.3.5. Deviation Map Sub-Window

The “**Deviation Map**” sub-window displays positions in longitude and latitude relative to the initial positioning point.



**Figure 9: Deviation Map Sub-Window**

#### **NOTE**

Use the mouse scroll wheel to zoom in/out on the deviation map and hold down the mouse scroll wheel to drag the deviation map.

**Table 1: Deviation Map Function Description**

Icon	Description
'A'	Display the average point
'F'	Fit track
'C'	Display CEP circle. Use the average point as a reference point by default
Red Point	Normal positioning point without RTK
Yellow Point	RTK Float positioning point
Green Point	RTK Fixed positioning point
Total (1300)	All positioning point counts
RTK Float (207: 15.92%)	Float point number and proportion
RTK Fixed (900: 69.23%)	Fixed point number and proportion
Setup	Click to set the reference point to calculate CEP

### 2.2.3.6. GNSS Signal View (Signal Level) Sub-Window

The sub-window in the figure below (“**Signal Level**”) displays GNSS signal view. The number above the flag represents the C/N<sub>0</sub> value. You can use the checkbox to select the satellite system to be displayed. If the flag is transparent, it means that the receiver is not tracking this satellite constellation and therefore there is no data available in NMEA GSA messages.




Figure 10: Signal View (Signal Level) Sub-Window

Table 2: Signal View Function Description

Button	Description
PRN	Satellite number of visible satellites.
BAND	Satellite frequency band.
AZI	Satellite azimuth in degrees.
ELE	Satellite elevation in degrees.

### 2.2.3.7. Sky View Sub-Window

The “**Sky View**” sub-window displays the azimuth and elevation angle (above the Horizon) of each visible navigation satellite per constellation and counts the number of all visible satellites of each positioning system.





Figure 11: Sky View Sub-Window

### 2.2.3.8. Messages View Sub-Window

The “**Messages View**” sub-window displays the message output by the receiver in the form of a parameter table.



**Figure 12: Messages View Sub-Window**

### 2.2.3.9. Configuration View Sub-window

This “**Configuration View**” sub-window is used to modify the receiver configuration. The configuration parameters may change depending on module type.




Figure 13: Configuration View Sub-Window

## 2.2.4. Setting Tab

Click “**Preferences**” to enter the Preferences Dialog, and set the supported protocol to parse in the Preferences Dialog.




Figure 14: Setting Tab Menu





Figure 15: Settings Dialog



### 2.2.5. Tools Tab

In the “**Tools**” tab menu:


- Select “**Command Console**” to send commands. See [Chapter 3.6 Send Command](#) for details.
- Select “**Static TTFF Testing**” to open the TTFF cycle testing tool. See [Chapter 3.4 TTFF](#) for details.
- Select “**Firmware Download**” to open the receiver firmware upgrade tool. See [Chapter 3.9 Firmware Download](#) for details.
- Select “**QGNSS log**” to open the log analysis tool and follow the step-by-step instructions.
- Select “**NTRIP**” to connect to NTRIP server. See [Chapter 3.8 NTRIP](#) for details.
- “**Switch Online Map**” can switch between the online maps used by QGNSS.
- Select “**NMAE Convert KML**” to open the tool for converting NMEA logs to a KML file. See [Chapter 2.2.5.2 NMEA Convert KML](#) for details.
- Select “**Coordinate Converter**” to open the coordinate conversion tool. See [Chapter 2.2.5.3 Coordinate Converter](#) for details.



**Figure 16: Tools Tab Menu**

### 2.2.5.1. Command Console

The “**Command Console**” tool is used for sending a command.



**Figure 17: Command Console Tool**

**Table 3: Command Console Function Description**

Button	Description
Enter	Whether "\r\n" is added behind the command.
HEX	If a binary command is sent, HEX checkbox should be selected.
Delay (ms)	After the command is sent, delay N milliseconds to send the next one.
Adds	Add the number of sent commands, and support 99 commands at most.
Checksum	Calculate Checksum for all NMEA commands.
Save	Save the command of the current window to the configuration file.
Load	Load the command from the configuration file to the window.
Run	Send the selected commands in a loop.
Clear	Clear all commands.

### 2.2.5.2. NMEA Convert KML

The “**NMEA Convert KML**” tool is used for converting NMEA logs to a KML format file.

- Click “**File Name(s)**” to select the NMEA file.
- Click “**File Name**” to select the output file location.
- Click “**OK**” to wait for the conversion to complete.




Figure 18: NMEA Convert KML Tool

### 2.2.5.3. Coordinate Converter

- In the “Coordinate Converter” tool:
  - Select **LLA(Deg)**, **LLA(Deg,Min)**, **LLA(Deg,Min,Sec)** or **ECEF(XYZ)** format and type in the corresponding values, taking “**LLA(Deg)**” as an example:

The screenshot shows the 'Coordinate Converter' window with the 'Calculate Distance' tab active. The 'LLA(Deg)' radio button is selected. The input fields are populated with the following values:

Format	Lat(D)	Lon(D)	Alt(m)
LLA(Deg)	31.82208222	117.11633695	129.40
LLA(Deg,Min)			
LLA(Deg,Min,Sec)			
ECEF(XYZ)			

At the bottom of the window, there are 'Clear' and 'Convert' buttons.

Figure 19: Coordinate Converter Tool – Enter Values

- Click “Convert” and the tool will convert the values to other formats.

**Coordinate Converter** [X]

Coordinate Converter   Calculate Distance

☒ LLA(Deg)  
 ☐ LLA(Deg,Min)  
 ☐ LLA(Deg,Min,Sec)  
 ☐ ECEF(XYZ)

**LLA(Deg)**

Lat(D)    Lon(D)    Alt(m)

**LLA(Deg,Min)**

Lat  D  M

Lon  D  M

Alt  m

**LLA(Deg,Min,Sec)**

Lat  D  M  S

Lon  D  M  S

Alt  m

**ECEF(XYZ)**

X    Y    Z

Clear   Convert

Figure 20: Coordinate Converter Tool – Convert Values

2. In the “**Calculate Distance**” page:
  - Enter the latitude and longitude of starting and end points to calculate the straight-line distance between two points.

The screenshot shows a software window titled "Coordinate Converter" with a close button (X) in the top right corner. Inside the window, there are two tabs: "Coordinate Converter" and "Calculate Distance". The "Calculate Distance" tab is selected. The interface includes three main input sections:


- Starting Point [°]:** Contains two input fields. The first is labeled "lat1" and contains the value "31.84468504". The second is labeled "lon1" and contains the value "117.10025436".
- End Point [°]:** Contains two input fields. The first is labeled "lat2" and contains the value "31.82159847". The second is labeled "lon2" and contains the value "117.11529995".
- Answer [km]:** Contains a single input field with the value "2.93433527".

At the bottom right of the window, there are two buttons: "Calculate" (highlighted with a blue border) and "Clear".

**Figure 21: Calculate Distance Tool**

### 2.2.6. DR Tab


In the “**DR**” tab menu, you can query the DR status of the receiver. DR interface status differs with module types.



**Figure 22: DR Status Window**

### 2.2.7. AGNSS Tab

Via the “**AGNSS**” window, you can download AGNSS files from the FTP server and download AGNSS data to the receiver through the serial port. See [Chapter 3.7 Send AGNSS Data](#) for details.



**Figure 23: AGNSS Window**

## 2.2.8. Windows Tab

In the “**Windows**” tab menu:

- Click “**Tile pattern**” to display the sub-window(s) to the center.
- Click “**Cascade**” to stack the sub-window(s) to the center.
- Click “**Close All**” to close all sub-windows.




Figure 24: Window Tab Menu





Figure 25: Tile Pattern Window






**Figure 26: Cascade Window**

## 2.2.9. Help Tab

In the “**Help**” tab menu:


- Click “**Check for Updates**” button to check if the tool is running the latest version of QGNSS.
- Click “**About**” button to see the current software version information.



**Figure 27: Help Tab Menu**














## 2.3. Tool Bar





Tool bar can be used for quick access to common operations.



**Figure 28: Tool Bar**

**Table 4: Description of Tool Bar Functions**

Icon	Function	Description
	Connect	Connect/disconnect serial port
	Set Device Information	Select module and set serial parameter(s)
	Open	Play log file
	Show Logfile in Explorer	Open the folder containing the saved log file(s)
	Cold Start	Send a Cold start command
	Warm Start	Send a Warm start command
	Hot Start	Send a Hot start command
	Full Cold Start	Send a Full cold start command
	Command Console	Open the Command console dialog
	GNSS Signal View	Open the Signal level sub-window
	Online Map	Open the Online Map sub-window
	Sky View	Open the Sky view sub-window
	Deviation Map	Open the Deviation map sub-window

Icon	Function	Description
	Data Dock	Open the Dock window (Data Dock and Analysis)
	NTRIP Client	Open the NTRIP Client dialog
	NTRIP Caster/Server	Disabled (not supported currently)
	Clear	Clear interface data

# 3 Common Operations

## 3.1. Connect to Receiver

Follow the below steps to connect the receiver to the QGNSS software utility:

**Step 1** Run the QGNSS tool.

**Step 2** Click the “**Set Device Information**” button on the tool bar to open the “**Device Information**” window.




Figure 29: Open Serial Port Configuration

**Step 3** Select the module and serial port parameters, and then click the “**OK**” button.





Figure 30: Serial Port Configuration Dialog

## 3.2. Log Play


Steps to replay a recorded log file:

**Step 1** Click the “**Play**” button to open the play dialog box.



**Figure 31: Log Play**

**Step 2** Select the file, and the play control window will pop up.



**Figure 32: Select the File**

**Step 3** Select the Read Rate(B/s) value, and then click “Exit” button.




Figure 33: Play Controller

Table 5: Controller Function Description

Button	Description
	Play and pause
	Play progress bar, click to drag the progress bar.
Read Rate 512B/s ▾	File reading speed
Exit	Exit

### 3.3. Restart Receiver

Choose a restart type and click the corresponding button in the tool bar to send the restart command to the receiver. For the description of these buttons, see [Table 4: Description of Tool Bar Functions](#) .




Figure 34: Restart Receiver

### 3.4. TTFF

Click “**Static TTFF Testing**” to open the TTFF window.




Figure 35: Open TTFF Window

**Step 1** Choose a “Restart type”.

**Step 2** Enter “Number of tests” and the “TTFF Time-out(Sec)” of each test.

**Step 3** Click “Run” button.





Figure 36: TTFF View

**NOTE**

Save the TTFF test log file (TTFF\_xxx\_xxx.log) in the log folder. Open the folder to view the log file.

### 3.5. Configure Receiver

Click “**Configuration View**” in the “**View**” tab drop-down menu to open “**Configuration View**” window.




**Figure 37: Open Configuration View**

**Step 1** Select the parameters to be configured and click “**Generating code**” button.

**Step 2** Click “**Send**” button to send the generated code to the receiver.

If the parameters support the query, click the “**Poll**” button to query the configuration parameters.






### Figure 38: Configuration View

### 3.6. Send Command

Click the “**Command Console**” in the “**Tools**” tab drop-down menu to open “**Command Console**” window. See [Figure 17 Command Console Tool](#) for details of “**Command Console**” interface.



**Figure 39: Open Command Console**

Send one command at a time:

1. Enter the command to be sent in the command box.
2. Click “**Send**” to send the command.


Send the selected commands in a loop:

1. Enter the commands to be sent in the command boxes one by one.
2. Select the checkboxes of the commands to be sent.
3. Click “**Run**” to send the commands in a loop.

For description of the functions of other buttons, see [Table 3: Command Console Function Description](#).

### 3.7. Send AGNSS Data


Click “Assistant GNSS Online” in the “AGNSS” tab drop-down menu to open “AGNSS” window.



**Figure 40: Open AGNSS Window**

**Step 1** Get AGNSS file:

1. Click “**Connect**” to connect to the FTP server.



**Figure 41: Connect to FTP Server**

#### NOTE

AGNSS file is used to improve the TTFF duration by providing long duration Ephemeris to the receiver.

2. Select the AGNSS file to be downloaded and click **“Download selected file”**.

**Download from server**

**FTP server information**

Address: ueclocator.com  
 User name: Default  
 Password: .....  
 [Disconnect] [Quit]

Logged onto agnss.ueclocator.com.

Name	Size	Owner	Group	Time
lto2dv5.brm	107100	user	group	2022-09-05
lto7dv5.brm	263676	user	group	2022-09-05

[Download selected file]

**AGNSS data**

[Select file] Specifies the file path to download to the module

**Time**

☒ Using UTC time  
☐ Using specified time: 2020-06-10 09:24:33  
 Leap second:   
 Time Accuracy[ms]:

**Position**

Latitude[deg]: Altitude[m]:   
 Longitude[deg]: Accuracy[m]:   
 [Use Current Position]

**Restart type**

☒ Cold start ☐ Warm start ☐ Hot start ☐ None  
☒ Time ☐ Position ☐ AGNSS Data  
 [Reset and Transfer]

**Figure 42: Download AGNSS File**

**Step 2** Send AGNSS data to the receiver:

1. Click **“Using UTC time”** to use the current time from receiver or click **“Using specified time”** to enter a time information.
2. Enter the position information (Latitude, Altitude, Longitude and Accuracy) or click **“Use Current Position”** to use the current position from receiver.
3. Choose a **“Restart type”**.
4. Check **“Position”** and **“AGNSS Data”**.
5. Click **“Reset and Transfer”**.

**Download from server**

**FTP server information**

Address: ueclocator.com  
 User name: Default  
 Password: .....  
 [Disconnect] [Quit]

Downloaded to directory lto2dv5.brm.

Name	Size	Owner	Group	Time
lto2dv5.brm	107100	user	group	2023-02-22
lto7dv5.brm	292740	user	group	2023-02-22

[Download selected file]

**AGNSS data**

[Select file] E:/GNSS/Tools/QGNSS/lto2dv5.brm

**Time**

☒ Using UTC time  
☐ Using specified time: 2020-06-10 09:24:33  
 Leap second:   
 Time Accuracy[ms]:

**Position**

Latitude[deg]: 31.8220951 Altitude[m]: 0  
 Longitude[deg]: 117.116338 Accuracy[m]:   
 [Use Current Position]

**Restart type**


☒ Cold start ☐ Warm start ☐ Hot start ☐ None  
☒ Time ☒ Position ☒ AGNSS Data  
 [Reset and Transfer]

**Figure 43: Send AGNSS Data**

## 3.8. NTRIP

The NTRIP is a gateway for GNSS modules to receive RTK corrections, which can effectively improve the positioning accuracy.

Click “**NTRIP Client**” in the “**Tools**” tab drop-down menu to open “**NTRIP Client**” window.



**Figure 44: Open NTRIP Client**

### 3.8.1. NTRIP Client

Use an NTRIP (V1.0) Client to connect to a standard NTRIP Caster, and follow these steps:

- Step 1** Enter the Address, Port, Username and Password. Contact Quectel Technical Support to get the Username and Password if necessary.
- Step 2** Click “**Update NTRIP source table**” and wait for the server to return mount point information.
- Step 3** Select “**NTRIP mount point**”.
- Step 4** Enter “**Request Interval**”.
- Step 5** Tick the checkbox next to “**Use manual position**” and a window as shown in [Figure 46: Set Manual Position](#) pops up for entering the relevant data; otherwise the fixed position of the module will be used.
- Step 6** Turn on the “**Connect to Host**” switch.




Figure 45: NTRIP Client





Figure 46: Set Manual Position

### 3.8.2. QuecRTK Client

QuecRTK is a high-precision RTK positioning and navigation service provided by Quectel, based on network RTK technology and supporting multiple constellations and frequency bands. The positioning accuracy can reach centimeter-level. By following the steps below, use QuecRTK to improve the module's positioning accuracy:

- Step 1** Enter the MCC, Company ID, Device ID and Licence Key. Contact Quectel Technical Support to get the Device ID and Licence Key if necessary.
- Step 2** Enter “**Request Interval**”.
- Step 3** Tick the checkbox next to “**Use manual position**” and a window as shown in [Figure 46: Set Manual Position](#) pops up for entering the relevant data; otherwise the fixed position of the module will be used.
- Step 4** Turn on the “**Connect to Host**” switch.



The screenshot shows the 'NTRIP Client' application window. The 'Client' tab is selected, and the 'QuecRTK' sub-tab is active. The interface includes several input fields for configuration: 'MCC' (a dropdown menu), 'Company ID', 'Device ID', and 'Licence Key' (all text boxes). Below these is a 'Request Interval (sec):' field with the value '1'. A checkbox labeled 'Use manual position' is currently unchecked. At the bottom, there is a 'Connect To Host' section with an 'OFF' toggle switch and a 'Monitor' button. A large, empty rectangular box occupies the right side of the window, likely for a map or data visualization.

**Figure 47: QuecRTK Client**

### 3.8.3. Data Monitor

Click “**Monitor**” to open the Data Monitor dialog box where you can view the differential correction data sent by the server.





Figure 48: RTK Data Monitor



### 3.9. Firmware Download

Connect to the receiver as explained in [Chapter 3.1 Connect to Receiver](#). Click “**Firmware Download**” in the “**Tools**” tab drop-down menu to open “**Firmware Download**” window.




**Figure 49: Open Firmware Download**

**Step 1** Click  to select the receiver firmware.

**Step 2** Click  to start the firmware download process and wait for the process to complete.

**Step 3** Reset module.



**Figure 50: Firmware Download Process**

**NOTE**

The steps for downloading the firmware by QGNSS tool may vary from module to module. See firmware upgrade guide document of specific module for details.

# 4 Appendix References

**Table 6: Terms and Abbreviations**

Abbreviation	Description
AGNSS	Assisted GNSS
BDS	BDS Navigation Satellite System
C/N <sub>0</sub>	Carrier-to-Noise-Density Ratio
CEP	Circular Error Probable
DR	Dead Reckoning
EPH	Ellipsoid Height
GLONASS	GLONASS Navigation Satellite System
GPS	Global Positioning System
IRNSS	Indian Regional Navigation Satellite System (NavIC)
KML	Keyhole Markup Language
MSL	Mean Sea Level
NTRIP	Networked Transport of RTCM via Internet Protocol
PRN	Pseudo Random Noise Code
QZSS	Quasi-Zenith Satellite System
RTK	Real-time Kinematic
SBAS	Satellite-Based Augmentation System
TTF	Time to First Fix
QuecRTK	Quectel RTK