

LC76F

Firmware Upgrade Guide

GNSS Module Series

Version: 1.0.

Date: 2021-09-14

Status: Released



At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

Quectel Wireless Solutions Co., Ltd.

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local offices. For more information, please visit:

<http://www.quectel.com/support/sales.htm>.

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/technical.htm>.

Or email us at: support@quectel.com.

Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an “as available” basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

Use and Disclosure Restrictions

License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by Quectel or any third party in advertising, publicity, or other aspects.

Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties ("third-party materials"). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

Disclaimer

- a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
- b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
- c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
- d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

Copyright © Quectel Wireless Solutions Co., Ltd. 2021. All rights reserved.

About the Document

Document Information

Title	LC76F Firmware Upgrade Guide
Subtitle	GNSS Module Series
Document Type	Firmware Upgrade Guide
Document Status	Released

Revision History

Version	Date	Description
-	2021-06-25	Creation of the document
1.0	2021-09-14	First official release

Contents

About the Document	3
Contents	4
Table Index	5
Figure Index	6
1 Introduction	7
2 Firmware Upgrade Process	8
2.1. Communication Between Host and Module	10
2.1.1. Handshake with Module	11
2.1.2. Send BE	12
2.1.3. Jump to BE	13
2.1.4. Sync with BE	13
2.1.5. Download Firmware	14
2.1.6. Reset	15
2.2. Sample Code for Checksum	16
3 Upgrade Implementation Example	17
4 Appendix Reference	22

Table Index

Table 1: List of Constants 8

Table 2: Baudrate..... 9

Table 3: Terms and Abbreviations 22

Figure Index

Figure 1: Firmware Upgrade Connection.....	7
Figure 2: Communication Between Host and Module	10
Figure 3: Handshake.....	11
Figure 4: Send BE.....	12
Figure 5: Jump to BE.....	13
Figure 6: Sync with BE.....	13
Figure 7: Download Firmware.....	14
Figure 8: Reset.....	15

1 Introduction

This document explains how to upgrade the firmware on Quectel LC76F GNSS module.

Following the procedure illustrated in this document, you can upgrade and download the firmware to the target GNSS module via the UART interface.




Figure 1: Firmware Upgrade Connection

2 Firmware Upgrade Process

This chapter explains all the necessary steps in the firmware upgrade process.

The following table defines all the constants used in this document.

Table 1: List of Constants

Constant Name	Constant Value	Steps
NMEA_START_CMD	\$PGKC75*1D\r\n	Figure 3: Handshake
BOOT_ROM_WRITE_CMD	0xA1	Figure 4: Send BE
BOOT_ROM_CHECKSUM_CMD	0xA4	Figure 4: Send BE
BE_START_ADDR	0x00000C00	Figure 4: Send BE Figure 5: Jump to BE
BOOT_ROM_JUMP_CMD	0xA8	Figure 5: Jump to BE
SYNC_CHAR	0xB0	Figure 6: Sync with BE
BE_MAJOR_VER	0x01	Figure 6: Sync with BE
BE_MINOR_VER	0x00	Figure 6: Sync with BE
BE_SPEED_CMD	0xE1	Figure 6: Sync with BE
BAUDRATE_FULL_SYNC_COUNT	0X00	Figure 6: Sync with BE
ACK	0x6B	Figure 6: Sync with BE Figure 7: Download Firmware
FW_START_ADDR	0x00000000	Figure 7: Download Firmware
FW_END_ADDR	0x0008E00B	Figure 7: Download Firmware
BE_MEM_CMD	0xE2	Figure 7: Download Firmware
BE_WRITE_CMD	0xE3	Figure 7: Download Firmware
BE_FINISH_CMD	0xE5	Figure 7: Download Firmware

PACKET_LENGTH	0x00000400	Figure 7: Download Firmware
CONT_CHAR	0xB9	Figure 7: Download Firmware
NMEA_CLEAR_CMD	\$PGKC41*1A\r\n	Figure 8: Reset
NMEA_RESET_CMD	\$PGKC30,3,1*1E\r\n	Figure 8: Reset

Table 2: Baudrate

Constant Name	Baudrate ID	Baudrate (bps)
UART_BAUD_921600	0x01	921600
UART_BAUD_460800	0x02	460800
UART_BAUD_230400	0x03	230400
UART_BAUD_115200	0x04	115200
UART_BAUD_57600	0x05	57600
UART_BAUD_38400	0x06	38400
UART_BAUD_19200	0x07	19200
UART_BAUD_14400	0x08	14400
UART_BAUD_9600	0x09	9600

NOTE

The bytes to be sent are transmitted in the big-endian format.

2.1. Communication Between Host and Module




Figure 2: Communication Between Host and Module

The following sections provide a guide on how the host communicates with module and sends commands and files to the module:

- Handshake with module
- Send BE (Burn Engine)
- Jump to BE
- Sync with BE
- Download firmware
- Reset

2.1.1. Handshake with Module

This section describes the handshake protocol in detail.

Host can send command **\$PGKC75*1D** make the module reset. After the module is reset, it will wait for "0x90" sent by the host for 300 milliseconds. If the "0x90" is not received, the handshake fails.




Figure 3: Handshake

2.1.2. Send BE

This section describes how to send the BE to the module.




Figure 4: Send BE

2.1.3. Jump to BE

This section describes how to jump to BE and run it.




Figure 5: Jump to BE

2.1.4. Sync with BE

This section describes how to sync with BE in detail.




Figure 6: Sync with BE

2.1.5. Download Firmware

This section describes how to download firmware to flash.




Figure 7: Download Firmware

2.1.6. Reset

This section describes how to reset the module.

After firmware download process is finished, the module will output NMEA message normally. Host will try to receive NMEA message in different baud rate. Once host receive NMEA head "\$", it will send **NMEA_CLEAR_CMD** and **NMEA_RESET_CMD** to reset the module in current baud rate. The firmware upgrade is completed after the module is reset.




Figure 8: Reset

2.2. Sample Code for Checksum

Checksum Code of BE File

```
uint16_t BE_compute_checksum (uint8_t *buf, uint32_t buf_len)
{
    uint16_t checksum = 0;
    if (buf == NULL || buf_len == 0) {
        return 0;
    }
    int i = 0;
    for (i = 0; i < buf_len / 2; i++) {
        checksum ^= *(uint16_t *) (buf + i * 2);
    }
    if ((buf_len % 2) == 1) {
        checksum ^= buf[i * 2];
    }
    return checksum;
}
```

Checksum Code of FW Packet

```
uint32_t FW_compute_simple_checksum (uint8_t *buf, uint32_t buf_len) {
    uint32_t checksum = 0;
    if (buf == NULL || buf_len == 0) {
        return 0;
    }
    for (int i = 0; i < buf_len; i++) {
        checksum += *(buf + i);
    }
    return checksum;
}
```

3 Upgrade Implementation Example

In this chapter you can find the example of firmware upgrade procedure.

```
//Host sends NMEA_START_CMD
//$PGKC75*1D
24 50 47 4B 43 37 35 2A 31 44 0D 0A
//Module will reset later
//Host continuously sends 0x90
90
//Module outputs NMEA message as before
45
//Host continuously sends 0x90
90
//Module outputs NMEA message as before
0D
//Host continuously sends 0x90
90
//Module outputs NMEA message as before
0D
//Host continuously sends 0x90
90
//Module resets
//Host continuously sends 0x90
90
90
//Module responds with 0x6F
6F
//Host sends 0x09
09
//Module responds with 0x6F as before
6F
//Module receives 0x09 and responds with 0xF6
F6
//Host sends 0x60
60
//Module responds with 0x9F
9F
```

```
//Host sends 0x06
06
//Module responds with 0xF9
F9
//Host sends BOOT_ROM_WRITE_CMD 0xA1
A1
//Module responds with 0xA1
A1
//Host sends BE_START_ADDR
00 00 0C 00
//Module responds with BE_START_ADDR
00 00 0C 00
//Host sends BE Length Num of Word
00 00 11 80
//Module responds with BE Length Num of Word
00 00 11 80
//Host sends first Burn Engine packet (256 Bytes)
00 00 E1 A0 00 00 E1 0F 10 C0 E3 A0 00 01 E1 80 ...
//Module responds with first Burn Engine packet (256 Bytes)
00 00 E1 A0 00 00 E1 0F 10 C0 E3 A0 00 01 E1 80 ...
//Host sends second Burn Engine packet (256 Bytes)
20 00 E0 82 00 00 20 83 00 04 21 50 30 08 85 91 ...
//Module responds with second Burn Engine packet (256 Bytes)
20 00 E0 82 00 00 20 83 00 04 21 50 30 08 85 91 ...
...
//Host sends last Burn Engine packet (<= 256 Bytes)
00 00 00 40 00 00 00 00 00 08 00 00 20 00 00 00 ...
//Module responds with last Burn Engine packet (<=256 Bytes)
00 00 00 40 00 00 00 00 00 08 00 00 20 00 00 00 ...
//Host sends BOOT_ROM_CHECKSUM_CMD
A4
//Module responds with BOOT_ROM_CHECKSUM_CMD
A4
//Host sends BE_START_ADDR
00 00 0C 00
//Module responds with BE_START_ADDR
00 00 0C 00
//Host sends BE Length Num of Word
00 00 11 80
//Module responds with BE Length Num of Word
00 00 11 80
//Module responds with checksum
40 69
//Host sends BOOT_ROM_JUMP_CMD
```

```
A8
//Module responds with BOOT_ROM_JUMP_CMD
A8
//Host sends BE_START_ADDR
00 00 0C 00
//Module responds with BE_START_ADDR
00 00 0C 00
//Module responds with SYNC_CHAR
B0
//Module responds with BE_MAJOR_VER
01
//Module responds with BE_MINOR_VER
00
//Host sends BE_SPEED_CMD
E1
//Host sends UART_BAUD_921600
01
//Host sends BAUDRATE_FULL_SYNC_COUNT
00
//Module responds with ACK
6B
//Host changes baud rate to 921600
//Host sends SYNC_CHAR
B0
//Module tries to respond with SYNC_CHAR in difference baud rate
00
//Host sends SYNC_CHAR
B0
//Module tries to respond with SYNC_CHAR in difference baud rate
00
//Host sends SYNC_CHAR
B0
//Module tries to respond with SYNC_CHAR in difference baud rate
AA
//Host sends SYNC_CHAR
B0
//Module tries to respond with SYNC_CHAR in difference baud rate
//Sync success
B0
//Host sends ACK
6B
//Module responds with ACK
6B
//Host sends BE_MEM_CMD
```

```

E2
//Host sends 0x01
01
//Host sends FW_START_ADDR
00 00 00 00
//Host sends FW_END_ADDR
00 08 E0 0B
//Module responds with ACK
6B
//Module responds with number of unchanged data blocks
00
//Host sends BE_WRITE_CMD
E3
//Host sends packet length
//0x00000400 = 1024 Bytes
00 00 04 00
//Host sends firmware first 4 bytes
82 DA 39 D6
//Module responds with ACK when burn engine has saved unchanged data
6B
//Module responds with ACK when sector erase done
6B
//Host sends first firmware packet except first 4 Bytes (1024 Bytes)
F9 CD F9 B7 DE 21 2E 3C 94 58 17 58 95 71 2D 83 ...
//Host sends checksum of first firmware packet (2 Bytes)
F2 4D
//Module responds with CONT_CHAR (continue char)
B9
//Host sends second firmware packet (1024 Bytes)
C2 B7 FA 50 50 75 7B 3C 49 45 96 BF 7E E9 97 52 ...
//Host sends checksum of first firmware packet (2 Bytes)
F4 27
//Module responds with CONT_CHAR (continue char)
B9
...
//Host sends last firmware packet (<= 1024 Bytes)
7B AD BA 9B 90 94 8D 57
//Host sends checksum of last firmware packet (2 Bytes)
04 85
//Module responds with CONT_CHAR (continue char)
B9
//Module responds with ACK when firmware upgrade was done
6B
//Module responds with ACK when checksum was done

```

6B//Host sends **BE_FINISH_CMD****E5**

//Host changes baud rate to 9600

//Module sends NMEA messages (**\$GNTXT,GK9501*7C\r\n**)**24 47 4E 54 58 54 2C 47 4B 39 35 30 31 2A 37 43 0D 0A**//Host sends **NMEA_CLEAR_CMD** (**\$PGKC41*1A\r\n**)**24 50 47 4B 43 34 31 2A 31 41 0D 0A**//Host sends **NMEA_RESET_CMD** (**\$PGKC30,3,1*1E\r\n**)**24 50 47 4B 43 33 30 2C 33 2C 31 2A 31 45 0D 0A**

4 Appendix Reference

Table 3: Terms and Abbreviations

Abbreviation	Description
ACK	Acknowledge
BE	Burn Engine
CMD	Command
FW	Firmware
GNSS	Global Navigation Satellite System
NMEA	NMEA (National Marine Electronics Association) 0183 Interface Standard
UART	Universal Asynchronous Receiver/Transmitter