

LC29D DR&RTK(0)

Application Note

GNSS Module Series

Version: 1.0

Date: 2021-06-18

Status: Released



Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:

Quectel Wireless Solutions Co., Ltd.

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local office. For more information, please visit:

<http://www.quectel.com/support/sales.htm>.

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/technical.htm>

Or email to support@quectel.com.

General Notes

Quectel offers the information as a service to its customers. The information provided is based upon customers' requirements. Quectel makes every effort to ensure the quality of the information it makes available. Quectel does not make any warranty as to the information contained herein, and does not accept any liability for any injury, loss or damage of any kind incurred by use of or reliance upon the information. All information supplied herein is subject to change without prior notice.

Disclaimer

While Quectel has made efforts to ensure that the functions and features under development are free from errors, it is possible that these functions and features could contain errors, inaccuracies and omissions. Unless otherwise provided by valid agreement, Quectel makes no warranties of any kind, implied or express, with respect to the use of features and functions under development. To the maximum extent permitted by law, Quectel excludes all liability for any loss or damage suffered in connection with the use of the functions and features under development, regardless of whether such loss or damage may have been foreseeable.

Duty of Confidentiality

The Receiving Party shall keep confidential all documentation and information provided by Quectel, except when the specific permission has been granted by Quectel. The Receiving Party shall not access or use Quectel's documentation and information for any purpose except as expressly provided herein. Furthermore, the Receiving Party shall not disclose any of the Quectel's documentation and information to any third party without the prior written consent by Quectel. For any noncompliance to the above requirements, unauthorized use, or other illegal or malicious use of the documentation and information, Quectel will reserve the right to take legal action.

Copyright

The information contained here is proprietary technical information of Quectel. Transmitting, reproducing, disseminating and editing this document as well as using the content without permission are forbidden. Offenders will be held liable for payment of damages. All rights are reserved in the event of a patent grant or registration of a utility model or design.

Copyright © Quectel Wireless Solutions Co., Ltd. 2021. All rights reserved.

About the Document

Document Information

Title	LC29D DR&RTK(0) Application Note
--------------	---

Subtitle	GNSS Module Series
-----------------	--------------------

Document Type	Application Note
----------------------	------------------

Document Status	Released
------------------------	----------

Revision History

Version	Date	Description
-	2021-05-14	Creation of the document
1.0	2021-06-18	First official release

Contents

About the Document	3
Contents	4
Table Index	5
Figure Index	6
1 Introduction	7
2 Configuration.....	8
2.1. Orientation.....	8
2.2. Mounting.....	10
2.3. DR Calibration	11
2.4. RTCM Input.....	11
3 Messages	13
3.1. PQTM Messages	13
3.1.1. PQTMINs	13
3.1.2. PQTMI MU	14
3.1.3. PQTMGPS	15
3.1.4. PQTMC FGEINSMSG.....	16
3.1.5. PQT MVEHMSG	17
3.1.5.1. When <MsgType> = 2	17
3.1.6. PQTMC FGWHEELTICK	18
3.1.7. PQT MQMPT.....	19
3.1.8. PQTMC FGORIENTATION	20
4 Appendix A References.....	22

Table Index

Table 1: Supported RTCM Input Messages	12
Table 2: Related Documents	22
Table 3: Terms and Abbreviations	22

Figure Index

Figure 1: Reference Frame	8
Figure 2: Module Orientation.....	8
Figure 3: Quectel LC29D Module Installation Example 1.....	9
Figure 4: Quectel LC29D Module Installation Example 2.....	9
Figure 5: Yaw Angle	10
Figure 6: Pitch and Roll Angles	11

1 Introduction

The dead reckoning (DR) and real-time kinematic (RTK) features, mounting, calibration, and messages related to DR and RTK of Quectel LC29D module are described in this document.

This document is applicable to the following variants of Quectel LC29D module:

- LC29D (A)
- LC29D (B)
- LC29D (C)

2 Configuration

2.1. Orientation

The reference frame axes definitions are shown below. The X-axis represents the vehicle forward direction, the positive direction of Y-axis is pointing to the right side of the vehicle, and the positive direction of Z-axis is downwards.




Figure 1: Reference Frame

The orientation of the module is shown below:




Figure 2: Module Orientation

Some Quectel LC29D module installation examples are show below:



Figure 3: Quectel LC29D Module Installation Example 1

If Quectel LC29D module is installed as in the figure above, the positive direction of X-axis is inverted, the direction of Y-axis is the same as in the reference frame, and the direction of Z-axis is also inverted compared to the reference frame; therefore, configuration should be **-XY-Z**, and the command is **\$PQTMCFGORIENTATION,1,-XY-Z*66**.




Figure 4: Quectel LC29D Module Installation Example 2

If Quectel LC29D module is installed as in the above figure, the X-axis is oriented in the direction of Y-axis of the reference frame, the Y-axis is oriented in the direction of the X-axis of the reference frame, and the direction of Z-axis is inverted to the direction of the Z-axis of reference frame; therefore, the configuration should be **-Y-X-Z**, and the command is **\$PQTMCFGORIENTATION,1,-Y-X-Z*4B**.

NOTE

Save the orientation configurations to flash with **\$PQTMSAVEPAR*5A** command and restart the module.

2.2. Mounting

When mounting the Quectel LC29D module on the carrier, you need to keep the yaw, pitch and roll angles within 5 degrees of the reference frame.




Figure 5: Yaw Angle




Figure 6: Pitch and Roll Angles

When mounting the Quectel LC29D module, make sure that $-5^\circ \leq \alpha \leq 5^\circ$, $-5^\circ \leq \beta \leq 5^\circ$.

2.3. DR Calibration

DR calibration steps:

- Step 1:** Fix the module on the vehicle frame. Any displacement, turn or tilt of the device, however small, will cause performance issues and/or void calibration.
- Step 2:** Calibration should be performed under good GNSS signal and clear sky conditions.
- Step 3:** Power up the module, then start the vehicle on a plain surface and keep it still for at least 30 s.
- Step 4:** Start driving the vehicle under good GNSS signal conditions. The module will start self-calibration, which would be completed in a few minutes.
- Step 5:** The calibration process ends when the `<SolType>` of `$PQTMINS` message indicates a combined solution (GNSS + DR). See **Chapter 3.1.1** for details about the message.

2.4. RTCM Input

Quectel LC29D module supports the RTCM version 3.3 input messages listed in table below.

Table 1: Supported RTCM Input Messages

Message Type	Description
1005	Stationary RTK Reference Station ARP
1006	Stationary RTK Reference Station ARP with Antenna Height
1074	GPS MSM4
1084	GLONASS MSM4
1094	Galileo MSM4
1124	BeiDou MSM4

3 Messages

3.1. PQTM Messages

This chapter introduces the PQTM messages (proprietary NMEA messages defined by Quectel) supported by Quectel LC29D module.

3.1.1. PQTMINS

This message outputs navigation results.

Type:

Output.

Synopsis:

```
$PQTMINSOL,<Timestamp>,<SolType>,<Lat>,<Lon>,<Height>,<VEL_N>,<VEL_E>,<VEL_D>,<Roll>,<Pitch>,<Heading>* <Checksum><CR><LF>
```

Parameter:

Field	Format	Unit	Description
<Timestamp>	Numeric	ms	Milliseconds since turn on. 32-bit unsigned integer.
<SolType>	Numeric	-	Solution type. 0 = DR not ready. Roll and Pitch ready. 1 = GNSS, Roll, Pitch and Relative Heading ready. DR not ready. 2 = GNSS + DR mode. DR calibrated. 3 = DR only mode.
<Lat>	Numeric	Degree	Latitude
<Lon>	Numeric	Degree	Longitude
<Height>	Numeric	Meter	Height
<VEL_N>	Numeric	m/s	Northward velocity

<VEL_E>	Numeric	m/s	Eastward velocity
<VEL_D>	Numeric	m/s	Downward velocity
<Roll>	Numeric	Degree	Roll angle.
<Pitch>	Numeric	Degree	Pitch angle.
<Heading>	Numeric	Degree	Heading angle.

Example:

```
$PQTMINS,42529,1,31.822038000,117.115182800,67.681000,,,,-0.392663,1.300793,0.030088*4D
```

NOTE

All angles are scaled from -180.0 to 179.9 with a wrap-around to 0.0 at +180.0.
 -180.0 = South, 180.0/0.0 = North, +90.0 = East, and -90.0 = West.

3.1.2. PQTMIMU

This message outputs the IMU Raw Data: Acceleration, Angular Rate and Hardware Wheel Ticks.

Type:

Output.

Synopsis:

```
$PQTMIMU,<Timestamp>,<ACC_X>,<ACC_Y>,<ACC_Z>,<AngRate_X>,<AngRate_Y>,<AngRate_Z>,<TickCount>,<LastTick_Timestamp>*<Checksum><CR><LF>
```

Parameter:

Field	Format	Unit	Description
<Timestamp>	Numeric	ms	Milliseconds since turn on. 32-bit unsigned integer.
<ACC_X>	Numeric	g	Acceleration in X-axis direction.
<ACC_Y>	Numeric	g	Acceleration in Y-axis direction.
<ACC_Z>	Numeric	g	Acceleration in Z-axis direction.
<AngRate_X>	Numeric	deg/s	Angular rate in X-axis direction.
<AngRate_Y>	Numeric	deg/s	Angular rate in Y-axis direction.

<AngRate_Z>	Numeric	deg/s	Angular rate in Z-axis direction.
<TickCount>	Numeric	-	Cumulative ticks.
<LastTick_Timestamp>	Numeric	ms	Last tick timestamp.

Example:

```
$PQTMIMU,42634,-0.006832,-0.022814,1.014552,0.315000,-0.402500,-0.332500,0,0*55
```

3.1.3. PQTMGPS

This message outputs the GNSS position status.

Type:

Output.

Synopsis:

```
$PQTMGPS,<Timestamp>,<TOW>,<Lat>,<Lon>,<Altitude>,<Speed>,<Yaw>,<Accuracy>,<HDOP>,<PDOP>,<NumSat>,<FixType>* <Checksum><CR><LF>
```

Parameter:

Field	Format	Unit	Description
<Timestamp>	Numeric	ms	Milliseconds since turn on. 32-bit unsigned integer.
<TOW>	Numeric	Second	Time of week.
<Lat>	Numeric	Degree	Latitude.
<Lon>	Numeric	Degree	Longitude.
<Altitude>	Numeric	Meter	Altitude.
<Speed>	Numeric	m/s	Ground speed (two-dimensional).
<Yaw>	Numeric	Degree	Heading of vehicle (two-dimensional).
<Accuracy>	Numeric	Meter	Horizontal accuracy estimate.
<HDOP>	Numeric	-	Horizontal dilution of precision.
<PDOP>	Numeric	-	Position (3D) dilution of precision.
<NumSat>	Numeric	-	Number of navigation satellites.

<FixType>	Numeric	-	Fix type. 0 = No fix. 2 = 2D fix. 3 = 3D fix.
-----------	---------	---	--

Example:

```
$PQTMGPS,671335,463792.000,31.822084600,117.115221100,59.4260,63.0420,0.0270,-171.7101,5.9890,1.3300,2.1100,3,18,*75
```

3.1.4. PQTMCFGEINSMMSG

This message sets/gets **PQTMINS**, **PQTMIMU** and **PQTMGPS** message settings.

Type:

Set/Get.

Synopsis:

```
$PQTMCFGEINSMMSG,<Set/Get>,<INS>,<IMU>,<GPS>,<Rate>* <Checksum><CR><LF>
```

Parameter:

Field	Format	Unit	Description
<Set/Get>	Numeric	-	0 = Get the current settings 1 = Set the message settings
<INS>	Numeric	-	Enable/disable PQTMINS message. 0 = Disable 1 = Enable
<IMU>	Numeric	-	Enable/disable PQTMIMU message. 0 = Disable 1 = Enable
<GPS>	Numeric	-	Enable/disable PQTMGPS message. 0 = Disable 1 = Enable
<Rate>	Numeric	Hz	Set the output rate of PQTMINS and PQTMIMU messages. It can be 10, 20, 50, 100. When set to 100, the maximum output rate is baud rate dependent.

Result:

If successful, the module returns:

```
$PQTMCFGEINSMMSGOK*16
```

If failed, the module returns:

```
$PQTMCFGEINSMMSGERROR*4A
```

Example:

```
//Set message settings
$PQTMCFGEINSMMSG,1,1,1,1,10*3F
$PQTMCFGEINSMMSGOK*16
//Get message settings
$PQTMCFGEINSMMSG,0*0E
$PQTMVEINSMMSG,0,1,1,1,10*7C
```

NOTE

For the above command to take effect, save it with **\$PQTMSAVEPAR*5A** command and restart the module.

3.1.5. PQTMVEHMSG

This message inputs/outputs vehicle information.

Type:

Input/Output.

Synopsis:

```
$PQTMVEHMSG,<MsgType>[,<Par1>,...,<ParN>]*<Checksum><CR><LF>
```

Parameter:

Field	Format	Unit	Description
<MsgType>	Numeric	-	Message type. 2 = Input/Output cumulative wheel tick via UART port
<Par1>,...,<ParN>	-	-	This field varies with the message type. See Chapter 3.1.5.1 for details

3.1.5.1. When <MsgType> = 2

Synopsis:

```
$PQTMVEHMSG,<MsgType>,<Timestamp>,<WheelTickCount>,<Reserved>*<Checksum><CR><LF>
```

Parameter:

Field	Format	Unit	Description
<MsgType>	Numeric	-	Message type. 2 = Input/Output cumulative wheel tick via UART port.
<Timestamp>	Numeric	ms	Milliseconds since turn on. 32-bit unsigned integer. While inputting vehicle message, keep this field as 0.
<WheelTickCount>	Numeric		Cumulative wheel ticks.
<Reserved>	Numeric	-	Reserved. Keep this field as 1.

Result:

Returns the cumulative wheel tick with timestamp.

Example:

```
//Input cumulative wheel ticks.
$PQTMVEHMSG,2,0,100,1*18
//Response
$PQTMVEHMSG,2,153954,100,1*27
```

NOTE

While inputting cumulative wheel ticks through UART port, make sure the input rate is at least 10 Hz.

3.1.6. PQTMCFGWHEELTICK

This message sets/gets the wheel tick pin and the ticks per meter.

Type:

Set/Get.

Synopsis:

```
$PQTMCFGWHEELTICK,<Set/Get>,<Edge>,<Pull>,<MPT>*<Checksum><CR><LF>
```

Parameter:

Field	Format	Unit	Description
<Set/Get>	Numeric	-	0 = Get the current settings 1 = Set the wheel tick pin and the ticks per meter

<Edge>	Numeric	-	Signal edge of wheel tick pin. 0 = Rising-edge (default) 1 = Falling-edge
<Pull>	Numeric	-	Pull state of wheel tick pin. 0 = No pull (default) 1 = Pull up 2 = Pull down
<MPT>	Numeric	Meter	Meters per tick. Default 0.25.

Result:

If successful, the module returns:

```
$PQTMCFGWHEELTICKOK*18
```

If failed, the module returns:

```
$PQTMCFGWHEELTICKERROR*44
```

Example:

```
//Set the wheel tick pin and the ticks per meter
$PQTMCFGWHEELTICK,1,0,0,0.25*34
$PQTMCFGWHEELTICKOK*18
//Get the current settings
$PQTMCFGWHEELTICK,0*00
$PQTMWHEELTICK,0,0,0,0.250000*77
```

NOTE

For the above command to take effect, save it with **\$PQTMSAVEPAR*5A** command and restart the module. Even though the ticks per meter value is set by this command, the DR engine will also calculate the real ticks per meter value.

3.1.7. PQTMQMPT

This message queries the current meters per tick value.

Type:

Query.

Synopsis:

```
$PQTMQMPT* <Checksum><CR><LF>
```

Parameter:

None.

Result:

If successful, the module returns:

```
$PQTMMPPT,<CurrentMPT>*<Checksum><CR><LF>
```

Field	Format	Unit	Description
<CurrentMPT>	Numeric	Meter	The current meters per tick value.

If failed, the module returns:

```
$PQTMQMPTERROR*58
```

Example:

```
$PQTMQMPT*00
$PQTMMPPT,0.250000*64
```

NOTE

Even though the meters per tick value is set by <MPT> in **\$PQTMCFGWHEELTICK**, the DR engine calculates/calibrates the meters per tick all the time. This command gets the real-time meters per tick value.

3.1.8. PQTMCFGORIENTATION

This message sets/gets the orientation.

Type:

Set/Get.

Synopsis:

```
$PQTMCFGORIENTATION,<Set/Get>,<ORI>*<Checksum><CR><LF>
```

Parameter:

Field	Format	Unit	Description
<Set/Get>	Numeric	-	0 = Get the current setting 1 = Set the orientation

<ORI>	String	-	Orientation string, it can be X, Y, Z or -X, -Y, -Z. Default “-Y-X-Z”. See Chapter 2.1 for details.
-------	--------	---	--

Result:

If successful, the module returns:

```
$PQTMCFGORIENTATIONOK*08
```

If failed, the module returns:

```
$PQTMCFGORIENTATIONERROR*54
```

Example:

```
//Set the orientation
$PQTMCFGORIENTATION,1,-Y-X-Z*4B
$PQTMCFGORIENTATIONOK*08
//Get the current orientation setting
$PQTMCFGORIENTATION,0*10
$PQTMORIENTATION,0,-Y-X-Z*08
```

NOTE

For the above command to take effect, save it with **\$PQTMSAVEPAR*5A** command and restart the module.

4 Appendix A References

Table 2: Related Documents

Document Name
[1] Quectel_LC29D_Protocol_Specification
[2] Quectel_LC29D_Hardware_Design

Table 3: Terms and Abbreviations

Abbreviation	Description
ARP	Antenna Reference Point
DR	Dead Reckoning
GLONASS	Global Navigation Satellite System (Russian)
GNSS	Global Navigation Satellite System
GPS	Global Positioning System
HDOP	Horizontal Dilution of Precision
IMU	Inertial Measurement Unit
MSM4	Type 4 Multiple Signal Message
NMEA	NMEA (National Marine Electronics Association) 0183 Interface Standard
PDOP	Position Dilution of Precision
RTK	Real-Time Kinematic
UART	Universal Asynchronous Receiver/Transmitter