

MC60 Series GNSS AT Commands Manual

GSM/GPRS/GNSS Module Series

Rev. MC60_Series_GNSS_AT_Commands_Manual_V1.3

Date: 2017-08-03



Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:

Quectel Wireless Solutions Co., Ltd.

7th Floor, Hongye Building, No.1801 Hongmei Road, Xuhui District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local office. For more information, please visit:

<http://quectel.com/support/sales.htm>

For technical support, or to report documentation errors, please visit:

<http://quectel.com/support/technical.htm>

Or email to: support@quectel.com

GENERAL NOTES

QUECTEL OFFERS THE INFORMATION AS A SERVICE TO ITS CUSTOMERS. THE INFORMATION PROVIDED IS BASED UPON CUSTOMERS' REQUIREMENTS. QUECTEL MAKES EVERY EFFORT TO ENSURE THE QUALITY OF THE INFORMATION IT MAKES AVAILABLE. QUECTEL DOES NOT MAKE ANY WARRANTY AS TO THE INFORMATION CONTAINED HEREIN, AND DOES NOT ACCEPT ANY LIABILITY FOR ANY INJURY, LOSS OR DAMAGE OF ANY KIND INCURRED BY USE OF OR RELIANCE UPON THE INFORMATION. ALL INFORMATION SUPPLIED HEREIN IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

COPYRIGHT

THE INFORMATION CONTAINED HERE IS PROPRIETARY TECHNICAL INFORMATION OF QUECTEL CO., LTD. TRANSMITTING, REPRODUCTION, DISSEMINATION AND EDITING OF THIS DOCUMENT AS WELL AS UTILIZATION OF THE CONTENT ARE FORBIDDEN WITHOUT PERMISSION. OFFENDERS WILL BE HELD LIABLE FOR PAYMENT OF DAMAGES. ALL RIGHTS ARE RESERVED IN THE EVENT OF A PATENT GRANT OR REGISTRATION OF A UTILITY MODEL OR DESIGN.

Copyright © Quectel Wireless Solutions Co., Ltd. 2017. All rights reserved.

About the Document

History

Revision	Date	Author	Description
1.0	2016-06-24	Hyman DING	Initial
1.1	2016-07-30	Hyman DING	Added the following new AT commands: AT+QGNSSTS/AT+QGNSSEPO/ AT+QGREFLOC/AT+QGEPOAID
1.2	2016-11-11	Hyman DING	Added new AT command: AT+QGEPOF
1.3	2017-08-03	Matt YE	Modified the description and example of AT+QGEPOF

Contents

About the Document	2
Contents	3
Table Index	4
1 Introduction	5
2 AT Commands for MC60 Series GNSS.....	6
2.1. Overview of AT Commands for MC60 Series GNSS	6
2.1.1. AT+QGNSSC Control Power Supply of GNSS Module.....	6
2.1.2. AT+QGNSSRD Read GNSS Navigation Information	7
2.1.3. AT+QGNSSCMD Send Commands to GNSS Module	8
2.1.4. AT+QGNSSSTS Get Time Synchronization Status for GNSS Module	8
2.1.5. AT+QGNSSSEPO Enable/Disable EPO™ Function	9
2.1.6. AT+QGREFLOC Set Reference Location Information for QuecFastFix Online.....	10
2.1.7. AT+QGEPOAID Trigger EPO™ Function.....	11
2.1.8. AT+QGEPOF EPO™ File Operation	11
3 Examples	14
3.1. AT+QGNSSC	14
3.2. AT+QGNSSRD.....	14
3.3. AT+QGNSSCMD	15
3.4. AT+QGNSSSTS	15
3.5. AT+QGNSSSEPO	15
3.6. AT+QGREFLOC.....	16
3.7. AT+QGEPOAID.....	16
3.8. AT+QGEPOF.....	17
3.9. Complete Example for QuecFastFix Online	17
4 Appendix A References	20
4.1. Related Documents	20
4.2. Terms and Abbreviations	20
4.3. Summary of CME ERROR Codes Related to GNSS.....	21

Table Index

TABLE 1: OVERVIEW OF AT COMMANDS FOR MC60 SERIES GNSS.....	6
TABLE 2: RELATED DOCUMENTS.....	20
TABLE 3: TERMS AND ABBREVIATIONS.....	20
TABLE 4: DIFFERENT CODING SCHEMES OF +CME ERROR RELATED TO GNSS: <ERR>	21

1 Introduction

GNSS, a featured function embedded in Quectel MC60 series module, can help customers get the current accurate coordinates, high precision time, etc.

MC60 series integrates both GNSS and GSM engines which can work as a whole (**All-in-one** solution) unit or work independently (**Stand-alone** solution) according to customer demands. In **All-in-one** solution, the internal GNSS module can be regarded as a peripheral of the whole unit, and is completely controlled by the GSM module, including power supply, UART communication, etc. In **Stand-alone** solution, the internal GNSS module and the GSM module work independently, and the GNSS has to be controlled separately.

MC60 series module currently includes two variants:

- OC: MC60CA-04-STD (supports BT3.0)
- OC: MC60ECA-04-BLE (supports BT4.0)

2 AT Commands for MC60 Series GNSS

2.1. Overview of AT Commands for MC60 Series GNSS

The commands below are effective only in **All-in-one** solution.

Table 1: Overview of AT Commands for MC60 Series GNSS

Command	Description
AT+QGNSSC	Control power supply of GNSS module
AT+QGNSSRD	Read GNSS navigation information
AT+QGNSSCMD	Send commands to GNSS module
AT+QGNSSSETS	Get time synchronization status for GNSS module
AT+QGNSSSEPO	Enable/Disable EPO™ function
AT+QGREFLOC	Set reference location information for QuecFastFix Online
AT+QGEPOAID	Trigger EPO™ function
AT+QGEPOF	EPO™ file operation

2.1.1. AT+QGNSSC Control Power Supply of GNSS Module

The command is used to control the power supply of GNSS module.

AT+QGNSSC Control Power Supply of GNSS Module	
Test Command AT+QGNSSC=?	Response +QGNSSC: (list of supported <mode>s) OK
Read Command AT+QGNSSC?	Response +QGNSSC: <mode>

	OK
Write Command AT+QGNSSC=<mode>	Response OK If there is an error related to ME functionality: +CME ERROR: <err>

Parameter

<mode>	<u>0</u>	Power off GNSS module
	1	Power on GNSS module

NOTE

In **Stand-alone** solution, the power supply of GNSS is controlled by an external circuit rather than the PIN GNSS_VCC_EN. In such case, command **AT+QGNSSC** cannot be used and thus can be ignored.

2.1.2. AT+QGNSSRD Read GNSS Navigation Information

The command is used to get the GNSS navigation information.

AT+QGNSSRD Read GNSS Navigation Information	
Test Command AT+QGNSSRD=?	Response +QGNSSRD: (list of supported <item>s) OK
Read Command AT+QGNSSRD?	Response +QGNSSRD: (information of all supported <item>s) OK
Write Command AT+QGNSSRD=<item>	Response +QGNSSRD: (information of <item>s) OK If there is an error related to ME functionality: +CME ERROR: <err>

Parameter

<item>	“NMEA/GGA”: Get GGA sentence “NMEA/GLL”: Get GLL sentence
---------------------	--

“NMEA/GSA”: Get GSA sentence
 “NMEA/GSV”: Get GSV sentence
 “NMEA/RMC”: Get RMC sentence
 “NMEA/VTG”: Get VTG sentence

2.1.3. AT+QGNSSCMD Send Commands to GNSS Module

The command is used to send commands to GNSS module, which allows customers to optionally use some functions to meet application demands.

AT+QGNSSCMD Send Commands to GNSS Module

Test Command AT+QGNSSCMD=?	Response +QGNSSCMD: (0,1),“cmdString” OK
Write Command AT+QGNSSCMD=<cmdType> >,<cmdString>	Response OK If there is an error related to ME functionality: +CME ERROR: <err>

Parameter

<cmdType>	<u>0</u> NMEA style command 1 Hex style command
<cmdString>	Command string

NOTE

Currently only **<cmdType>=0** is supported.

2.1.4. AT+QGNSSSTS Get Time Synchronization Status for GNSS Module

The command is used to get time synchronization status for GNSS module. Time plays a very important role in EPO™ function.

AT+QGNSSSTS Get Time Synchronization Status for GNSS Module

Test Command AT+QGNSSSTS=?	Response +QGNSSSTS: <status> OK
--------------------------------------	---

Read Command AT+QNSSTS?	Response +QNSSTS: <status> OK
-----------------------------------	---

Parameter

<status>	0	Time is not synchronized
	1	Time is synchronized successfully

NOTE

Exact time is very important to EPO™ function. So customers must ensure the time is valid before using EPO™ function.

2.1.5. AT+QNSSEPO Enable/Disable EPO™ Function

The command is used to enable or disable EPO™ function.

AT+QNSSEPO Enable/Disable EPO™ Function

Test Command AT+QNSSEPO=?	Response +QNSSEPO: (list of supported <mode>s)[,<account_id>] OK
Read Command AT+QNSSEPO?	Response +QNSSEPO: <mode>,<account_id> OK
Write Command AT+QNSSEPO=<mode>[,<account_id>]	Response OK If there is an error related to ME functionality: +CME ERROR: <err>

Parameter

<mode>	<u>0</u>	Disable EPO™ function
	1	Enable EPO™ function
<account_id>	<u>2</u>	Set account ID for EPO™ function

NOTES

1. The parameter **<account_id>** only supports 2. It can be omitted and 2 will be its default value when it is omitted.
2. The EPO™ function should be enabled after the time is synchronized successfully.

2.1.6. AT+QGREFLOC Set Reference Location Information for QuecFastFix Online

The command is used to set reference location information for QuecFastFix Online function.

AT+QGREFLOC Set Reference Location Information for QuecFastFix Online

Test Command AT+QGREFLOC=?	Response +QGREFLOC: <ref_latitude>,<ref_longitude> OK
Read Command AT+QGREFLOC?	Response +QGREFLOC: <ref_latitude>,<ref_longitude> OK
Write Command AT+QGREFLOC=<ref_latitude>,<ref_longitude>	Response OK If there is an error related to ME functionality: +CME ERROR: <err>

Parameter

<ref_latitude>	Latitude information of the reference location
<ref_longitude>	Longitude information of the reference location

NOTES

1. The range of **<ref_latitude>** is -90°~90° North Latitude, and the range of **<ref_longitude>** is -180°~180° East Longitude. The input format of the parameter should retain 6 decimal places, and the unit is degree.
2. The command works for QuecFastFix Online function and should be set before executing **AT+QGNSSSEPO=1**.

2.1.7. AT+QGEPOAID Trigger EPO™ Function

The command is used to trigger EPO™ function.

AT+QGEPOAID Trigger EPO™ Function

Test Command AT+QGEPOAID=?	Response OK
Execution Command AT+QGEPOAID	Response OK If there is an error related to ME functionality: +CME ERROR: <err>

NOTES

1. If GNSS is powered on already, customers could use this command to trigger EPO™ function after executing **AT+QGNSSEPO=1**.
2. If execute **AT+QGNSSEPO=1** first and then power on GNSS, executing this command will not trigger EPO™ function.

2.1.8. AT+QGEPOF EPO™ File Operation

The command is used to operate EPO™ related files, including deleting related files, getting file size and querying validity period of EPO™ files.

AT+QGEPOF EPO™ File Operation

Test Command AT+QGEPOF=?	Response +QGEPOF: (list of supported <mode> s), (list of supported <index> s) OK
Write Command AT+QGEPOF=<mode>,<index>	Response If <mode> is 0, response: +QGEPOF: <size_a>,<size_b>,<size_c> OK If <mode> is 1, response: OK If <mode> is 2, response: +QGEPOF: <time> OK

If there is an error related to ME functionality:

+CME ERROR: <err>

Parameter

<mode>	Operation mode	
	0	Get EPO™ file size
	1	Delete EPO™ file
	2	Query validity period of EPO™ files
<index>	EPO™ file selection	
	1	Select the EPO™ file containing 6 hours of data
	2	Select the EPO™ file containing the first 3 days of data
	3	Select the EPO™ file containing the second 3 days of data
	255	Select the above 3 files
<size_a>	Integer value. Positive numbers indicate the file size, and negative numbers indicate failed file operation.	
	0-4032	Size of the EPO™ file containing 6 hours of data
	-9	File not found
	-16	File access denied
	-19	Path not found
	Other negative values	Other failed file operation
<size_b>	Integer value. Positive numbers indicate the file size, and negative numbers indicate failed file operation.	
	0-48384	Size of the EPO™ file containing the first 3 days of data
	-9	File not found
	-16	File access denied
	-19	Path not found
	Other negative values	Other failed file operation
<size_c>	Integer value. Positive numbers indicate the file size, and negative numbers indicate failed file operation.	
	0-48384	Size of the EPO™ file containing the second 3 days of data
	-9	File not found
	-16	File access denied
	-19	Path not found
	Other negative values	Other failed file operation
<time>	String type. The queried validity period of EPO™ files	
	The format is "yyyy-MM-dd hh:mm:ss" (UTC time), and the characters indicate year, month, day, hour, minute and second respectively.	
	-9	File not found
	-16	File access denied

-19	Path not found
Other negative values	Other failed file operation

NOTES

1. If the EPO™ files are deleted, there is a need to trigger EPO™ function again. For more details, please refer to *Quectel_MC60_GNSS_AGPS_Application_Note*.
2. If **<mode>** is 2, **<index>** can be omitted.
3. Commands **AT+QGEPOF=1,1**, **AT+QGEPOF=1,2** and **AT+QGEPOF=1,3** are only for testing purpose. Please use **AT+QGEPOF=1,255** in the real application.

3 Examples

3.1. AT+QGNSSC

```

AT+QGNSSC?           //Query GNSS power status.
+QGNSSC: 0           //GNSS is powered off.
OK
AT+QGNSSC=1         //Power on GNSS.
OK
    
```

3.2. AT+QGNSSRD

```

AT+QGNSSRD?           //Inquire GNSS NMEA sentence.
+QGNSSRD: $GNRMC,034035.000,A,3150.8617,N,11711.9038,E,3.02,183.45,240516,,,A*75
$GNVTG,183.45,T,,M,3.02,N,5.59,K,A*20
$GNGGA,034035.000,3150.8617,N,11711.9038,E,1,4,1.50,40.9,M,0.0,M,,*44
$GPGSA,A,3,26,21,,,,,,,,,1.75,1.50,0.91*0A
$GLGSA,A,3,82,70,,,,,,,,,1.75,1.50,0.91*1C
$GPGSV,3,1,12,16,67,308,,26,58,021,16,23,40,307,,31,40,088,*7F
$GPGSV,3,2,12,08,17,199,,09,14,320,,21,10,086,14,14,10,153,*73
$GPGSV,3,3,12,22,09,226,,193,06,165,,32,03,154,,29,01,034,*45
$GLGSV,3,1,09,81,44,073,,79,40,041,,82,38,145,15,80,36,323,*66
$GLGSV,3,2,09,70,30,290,16,69,26,225,,78,12,078,,88,09,027,*64
$GLGSV,3,3,09,71,05,334,*5B
$GNGLL,3150.8617,N,11711.9038,E,034035.000,A,A*4C

OK
AT+QGNSSRD="NMEA/RMC" //Inquire RMC information.
+QGNSSRD: $GNRMC,034036.000,A,3150.8612,N,11711.9045,E,2.74,178.00,240516,,,A*7C

OK
AT+QGNSSRD="NMEA/GSA" //Inquire GSA information.
+QGNSSRD: $GPGSA,A,3,26,21,,,,,,,,,1.76,1.50,0.91*09
$GLGSA,A,3,82,70,,,,,,,,,1.75,1.50,0.91*1C

OK
AT+QGNSSRD?           //Inquire GNSS NMEA sentence.
    
```

```
+QGNSSRD: $GNRMC,034039.000,A,3150.8596,N,11711.9049,E,2.13,194.12,240516,,,A*70
$GNVTG,194.12,T,,M,2.13,N,3.95,K,A*23
$GNGGA,034039.000,3150.8596,N,11711.9049,E,1,5,1.50,38.7,M,0.0,M,,*44
$GPGSA,A,3,22,26,21,,,,,,,,,1.75,1.50,0.91*0A
$GLGSA,A,3,82,70,,,,,,,,,1.75,1.50,0.91*1C
$GPGSV,3,1,12,16,67,308,,26,58,021,17,23,40,307,,31,40,088,*7E
$GPGSV,3,2,12,08,17,199,,09,14,320,,21,10,086,12,14,10,153,*75
$GPGSV,3,3,12,22,09,226,16,193,06,165,,32,03,154,,29,01,034,*42
$GLGSV,3,1,09,81,44,073,,79,40,041,,82,38,145,16,80,36,323,*65
$GLGSV,3,2,09,70,30,290,16,69,26,225,,78,12,078,,88,09,027,*64
$GLGSV,3,3,09,71,05,334,*5B
$GNGLL,3150.8596,N,11711.9049,E,034039.000,A,A*4C

OK
```

3.3. AT+QGNSSCMD

```
AT+QGNSSCMD=0,"$PMTK605*31" //Inquire GNSS version information.
```

OK

```
+QGNSSCMD: $PMTK705,AXN_3.82_3333_16051101,0001,MC60-GNSS,1.0*2A
```

3.4. AT+QGNSSTS

```
AT+QGNSSTS=? //Test command
```

```
+QGNSSTS: (0,1)
```

OK

```
AT+QGNSSTS? //Read time synchronization mode and status.
```

```
+QGNSSTS: 1 //Time is synchronized successfully.
```

OK

3.5. AT+QGNSSEPO

```
AT+QGNSSEPO=? //Test command
```

```
+QGNSSEPO: (0,1)[,<account_id>]
```

OK

```
AT+CREG?;+CGREG? //Check network status.
```

```
+CREG: 0,1
```

```
+CGREG: 0,1

OK
AT+QGNSSSEPO=1           //Enable EPO™ function.
OK
AT+QGNSSSEPO?           //Read EPO™ status.
+QGNSSSEPO: 1,2

OK
```

3.6. AT+QGREFLOC

```
AT+QGREGLOC=?           //Test command
+QGREFLOC: <ref_latitude>,<ref_longitude>

OK
AT+QGREFLOC=31.507985,117.119750
OK
```

3.7. AT+QGEPOAID

```
AT+QGNSSC=1           //Power on GNSS.
OK
AT+CREG?;+CGREG?     //Check network status.
+CREG: 0,1

+CGREG: 0,1

OK
AT+QGNSSSTS?         //Inquire time synchronization status.
+QGNSSSTS: 1

OK
AT+QGNSSSEPO=1
OK
AT+QGEPOAID
OK
```

3.8. AT+QGEPOF

```
AT+QGEPOF=?           //Test command
+QGEPOF: (0-2),(1-3,255)

OK
AT+QGEPOF=0,255       //Get EPO™ file size.
+QGEPOF: -9,48384,48384

OK
AT+QGEPOF=2           //Query validity period of EPO™ files.
+QGEPOF: 2017-02-19 00:00:00

OK
AT+QGEPOF=1,255       //Delete all EPO™ files.
OK
AT+QGEPOF=0,255
+QGEPOF: -9,-9,-9

OK
AT+QGEPOF=2
+QGEPOF: -9

OK
```

3.9. Complete Example for QuecFastFix Online

```
AT+QGNSSC=1           //Power on GNSS.
OK
AT+QIFGCNT=2
OK
AT+QICSGP=1,"CMNET"
OK
AT+QGNSSSTS?         //Read time synchronization status.
+QGNSSSTS: 0

OK
AT+CREG?;+CGREG?     //Check network status.
+CREG: 0,2

+CGREG: 0,2

OK
```

```

AT+CREG?;+CGREG? //Check network status.
+CREG: 0,1

+CGREG: 0,1

OK
AT+QGNSSSTS? //Read time synchronization status.
+QGNSSSTS: 1 //Time synchronization completed.

OK
AT+QGREFLOC=31.507985,117.119750 //Set reference location information for QuecFastFix Online.
OK
AT+QGNSSSEPO=1 //Enable EPO™ function.
OK
AT+QGEPOAID //Trigger EPO™ function.
OK
AT+QGNSSRD?
+QGNSSRD: $GNRMC,125349.093,V,,,,,0.00,0.00,010716,,,N*50
$GNVTG,0.00,T,,M,0.00,N,0.00,K,N*2C
$GNGGA,125349.093,,,,,0,0,,,M,,M,,*54
$GPGSA,A,1,,,,,,,,,,,,,*1E
$GLGSA,A,1,,,,,,,,,,,,,*02
$GPGSV,1,1,02,09,,,29,06,,,29*74
$GLGSV,1,1,00*65
$GNGLL,,,,,125349.093,V,N*66

OK
AT+QGNSSRD?
+QGNSSRD: $GNRMC,125350.093,V,,,,,0.00,0.00,010716,,,N*58
$GNVTG,0.00,T,,M,0.00,N,0.00,K,N*2C
$GNGGA,125350.093,,,,,0,0,,,M,,M,,*5C
$GPGSA,A,1,,,,,,,,,,,,,*1E
$GLGSA,A,1,,,,,,,,,,,,,*02
$GPGSV,1,1,02,09,,,29,06,,,29*74
$GLGSV,1,1,00*65
$GNGLL,,,,,125350.093,V,N*6E

OK
.....
AT+QGNSSRD?
+QGNSSRD: $GNRMC,125353.092,A,3150.8278,N,11711.9888,E,0.31,111.02,010716,,,A*7C
$GNVTG,111.02,T,,M,0.31,N,0.58,K,A*2F
$GNGGA,125353.092,3150.8278,N,11711.9888,E,1,5,1.63,145.5,M,0.0,M,,*7A
$GPGSA,A,3,06,09,07,02,12,,,,,,,,,1.83,1.63,0.83*0E

```

```
$GLGSA,A,3,,,,,,,,,,,,,1.83,1.63,0.83*1B
$GPGSV,4,1,15,02,68,022,28,05,61,286,,06,37,091,32,13,31,181,*73
$GPGSV,4,2,15,19,25,155,,29,24,318,,20,18,257,,12,17,243,25*7E
$GPGSV,4,3,15,25,13,278,,09,11,039,31,07,06,081,26,15,06,205,*7A
$GPGSV,4,4,15,30,05,107,,17,01,151,,193,,,*44
$GLGSV,1,1,04,85,77,105,,86,41,334,,84,26,139,,72,12,227,*65
$GNGLL,3150.8278,N,11711.9888,E,125353.092,A,A*4B
```

OK

AT+QGNSSRD?

```
+QGNSSRD: $GNRMC,125354.092,A,3150.8278,N,11711.9888,E,0.31,111.02,010716,,,A*7B
$GNVTG,111.02,T,,M,0.31,N,0.58,K,A*2F
$GNGGA,125354.092,3150.8278,N,11711.9888,E,1,5,1.63,145.5,M,0.0,M,,*7D
$GPGSA,A,3,06,09,07,02,12,,,,,,,,,1.83,1.63,0.83*0E
$GLGSA,A,3,,,,,,,,,,,,,1.83,1.63,0.83*1B
$GPGSV,4,1,15,02,68,022,28,05,61,286,,06,37,091,32,13,31,181,*73
$GPGSV,4,2,15,19,25,155,,29,24,318,,20,18,257,,12,17,243,25*7E
$GPGSV,4,3,15,25,13,278,,09,11,039,31,07,06,081,26,15,06,205,*7A
$GPGSV,4,4,15,30,05,107,,17,01,151,,193,,,*44
$GLGSV,1,1,04,85,77,105,,86,41,334,,84,26,139,,72,12,227,*65
$GNGLL,3150.8278,N,11711.9888,E,125354.092,A,A*4C
```

OK

4 Appendix A References

4.1. Related Documents

Table 2: Related Documents

SN	Document Name	Remark
[1]	NMEA 0183 Version 3.01	Standard for Interfacing Marine Electronic Devices
[2]	Quectel_MC60_Series_Hardware_Design	MC60 series hardware design
[3]	Quectel_MC60_GNSS_AGPS_Application_Note	MC60 GNSS AGPS application note

4.2. Terms and Abbreviations

Table 3: Terms and Abbreviations

Abbreviation	Description
GGA	Global Positioning System Fixed Data
GLL	Geographic Latitude and Longitude
GNSS	Global Navigation Satellite System
GSA	GNSS DOP and Active Satellites
GSM	Global System for Mobile Communication
GSV	GNSS Satellites in View
ID	Identification

ME	Mobile Equipment
NMEA	National Marine Electronics Association
RMC	Recommended Minimum Specific GNSS Data
UART	Universal Asynchronous Receiver & Transmitter
UTC	Coordinated Universal Time
VTG	Course Over Ground and Ground Speed

4.3. Summary of CME ERROR Codes Related to GNSS

Table 4: Different Coding Schemes of +CME ERROR Related to GNSS: <err>

Code of <err>	Meaning
7101	Invalid parameter
7102	Not supported
7103	Operation failed